
KAWAI MIDI PATCHBAY MAV-8

Owner's Manual

Panel Location Guide



Controls

(1) MIDI IN connectors A-D

These accept signals from the MIDI OUT and MIDI THRU connectors of other MIDI instruments. Up to four instruments can be connected.

(2) Selectors 1-8

These route the signals from the MIDI IN connectors A-D to the MIDI OUT connectors 1-8. The fifth position, OFF, cuts all output to the connector — that is, makes it mute.

(3) MIDI OUT connectors 1-8

These transmit signals to the MIDI IN connectors on up to eight MIDI instruments.

Note: It is also possible to connect more instruments by daisy-chaining them through the MIDI THRU connectors on these eight instruments.

(4) POWER switch and LED

The LED in the switch lights when the unit is operational.

(5) AC IN jack

This connects to the AC power adapter.

Care and Maintenance

- Connect the AC adapter supplied with the instrument to a power outlet with a voltage matching the one listed rating on the adapter.
- Avoid continued use or storage in the presence of the following environmental factors as they may contribute to faulty operation or breakdowns:
 - * Exposure to direct sunlight
 - Excessive heat or humidity
 - * Sand or dust
 - Excessive vibration
- Do not force the selectors as excessive force can damage the contacts.
- Do not change selector settings or cut the power while the unit is transmitting as transients may affect other MIDI instruments, resulting in stuck notes or other problems.
- Always turn the MAV-8 on first so as to avoid sending improper signals to other MIDI instruments.

Specifications

Controls

Input Selectors

Jacks

MIDI IN MIDI OUT

Dimensions

Weight

Accessories

Power supply

Current consumption

1-8 (Five positions: A/B/C/D/OFF)

A-C (Rear panel), D (Front panel)

1-7 (Rear panel), 8 (Front panel) $482 \times 118 \times 44 \text{ mm} (19 \times 4\% \times 1\%)$

(fits EIA 1U rack)

1.7 kg 3.8 lbs.

AC adapter

AC adapter

50 mA